

## Polarization-maintaining Fiber Cables (PM Fibers)

polarization-maintaining, single-mode fibers series PMC with Gaussian intensity profile



### FEATURES

Polarization-maintaining, single-mode fiber cable with Gaussian intensity distribution and low-stress fiber connectors.

- Cut-off wavelengths from 360 nm to 1550 nm
- Wavelengths covering altogether 360nm to 1800 nm - each fiber with an operational wavelength range of about 100-300 nm.
- Special broadband fiber RGB with an operational wavelength range 400-680 nm
- Pure Silica core fibers with low attenuation for wavelengths < 460 nm
- High PER fiber cables
- Measured values for fiber NA:  $NAe^2$
- Special fibers with small NA for smaller power density in the fiber core
- Fiber patch cable with Ø 900 µm buffer or as Ø 3 mm Cable with Kevlar strain-relief
- Customer-specified connectors type FC, AVIM (comp. to LSA) or E2000 with 0°-polish or 8°-polish
- Polarization axis is indicated by connector index key (slow axis), only for Type FC connectors
- Amagnetic titanium connectors for connectors of type FC PC or FC APC
- End caps for a smaller power density at the fiber end-faces



## DESCRIPTION

Polarization-maintaining, single-mode fiber cable (PM fiber cable) with Gaussian intensity distribution and low-stress fiber connectors.

## Fiber

The fiber is a [polarization-maintaining](#), single-mode fiber, defined by its [NA](#) and its [cut-off wavelength](#). The nom. NA is specified by the fiber manufacturer. Additionally the effective numerical  $NA_{\text{eff}}$  is measured for each fiber batch by Schäfter+Kirchhoff. Cut-off wavelengths range from 360 nm to 1550 nm and the fibers altogether cover a wavelength range of 360 nm to 1800 nm. Each fiber has an operational wavelength range of about 100-300 nm. Besides the nominal cut-off wavelength  $\lambda_{\text{co}}$ , Schäfter+Kirchhoff also offers measured data for the cut-off wavelength for each individual fiber cable.

Some fibers have special features e.g.

- [Pure silica core](#) for long-term stable low attenuation and high transmission for < 460 nm
- Special fibers with extra low NA that leads to a lower power density in the fiber core compared to a standard fiber with standard NA. The maximum power level (described by the [Brillouin threshold](#)) that can be transmitted in the fiber is shifted to a higher value. Please note that there are other limiting factors e.g. concerning the [fiber end faces](#).

## Fiber Cable

The fiber length can be customer-specified (there is a [minimum fiber length](#)). The polarization-maintaining [fiber cables](#) are offered as Ø 900 µm buffer in black, or a Ø 3 mm cable in black with Kevlar strain-relief.

## Fiber Connectors

For each fiber end the fiber connectors can be selected from a wide range of [connector types](#) (FC, AVIM (compatible with LSA), E2000) with 0°-polish or 8°-polish. All fiber connectors of type FC assembled by Schäfter+Kirchhoff have an alignment index (key). The wide key (type "N") fiber connector has an alignment index (key) of 2.14 mm width. The narrow key (type "R") fiber connector has an alignment index (key) of 2 mm width. Special fiber connectors are available so that the fiber cable is vacuum compatible down to  $10^{-7}$  mbar (only Ø 900 µm buffer fiber cables).

## High PER fibers

During the manufacturing of PM fibers, great care is taken to ensure a high [PER](#). Typical PER values are  $\geq 21$  dB to  $\geq 26$  dB depending on wavelength and connector type.

## End Caps

The fiber connectors can be equipped with an [end cap connector](#). This means that a short piece of fiber (< 300 µm) without a core is spliced onto the polarization-maintaining fiber. Without a fiber core to confine the beam, the mode field diameter of the beam already starts to diverge within the fiber end cap, significantly reducing the power density at the fiber end-face.

## Amagnetic fiber connectors

For FC PC or FC APC type connectors [amagnetic versions](#) completely made of titanium can be selected. Those connectors have a ceramic ferrule.

# TECHNOTES

- [Numerical Aperture / Effective Numerical Aperture](#)  
[Why is it best to define an effective numerical aperture  \$NA\_{\text{eff}}\$ ?](#)

[Typical effective Numerical Apertures](#)

[Typical values for the effective numerical aperture](#)

- [Cut-off wavelength](#)

[Definition of cut-off wavelength and the fiber working range](#)

- [Mode field diameter](#)

[Definition of mode field diameter MFD](#)

- [MFD and NA Wavelength Dependency](#)

[How do MFD and NA vary with wavelength?](#)

- [Mismatch / NA Mismatch and Overlap](#)

[Overlap and coupling efficiency when using fibers of different NA, different Mode field or different focal lengths](#)

- [Fiber Attenuation](#)

[Attenuation of single-mode and PM fibers depending on wavelength.](#)

- [Pure Silica core fibers \(Si\)](#)

[Pure silica core fibers \(Si\)](#)

- [Polarization-maintaining Fibers \(PM Fibers\)](#)

[Why are some fibers polarization-maintaining?](#)

- [Characterizing Polarization-maintaining Fibers \(PM Fibers\)](#)

[How to characterize PM fibers.](#)

- [RGB Polarization-maintaining Fibers](#)

[What is an RGB PM fiber?](#)

- [High Power Phenomena](#)

[Stimulated Brillouin Scattering and fiber end-face effects](#)

- [End cap fibers](#)

[What are end caps and why should I use them?](#)

- [Fiber Patch Cable Types](#)

[Details on the structure of 3 mm and 900 µm fiber cables.](#)

- [Fiber Connector Options](#)

[FC, AVIM and E2000](#)

- [Amagnetic fiber connectors](#)

[Special features of titanium connectors](#)

- [Connecting single-mode and PM fibers to a fiber coupler](#)

[How to correctly insert a fiber into the receptacle of a fiber coupler](#)

## FAQ

### Connector Type FC PC and FC APC

### How do I attach a fiber cable?

To prevent damage to the sensitive fiber end-face, always insert the fiber connector's ferrule at an angle, with the connector key properly aligned to the receptacle notch. When the ferrule tip is safely located in the inner cylinder of the receptacle, align the connector to the receptacle axis and carefully introduce the connector into the fiber coupler.

Then, orient the connector key in a way that it is pressed gently onto the right-hand side of the receptacle notch ("right-hand orientation rule").

Gently screw on the connector cap nut onto the receptacle until it is finger-tight.

Gently tighten the fiber grub screw to reduce the free play of the ferrule in the receptacle.

### What is the "right-hand orientation rule"?

When the ferrule tip is safely located in the inner cylinder of the receptacle, align the connector to the receptacle axis and carefully introduce the connector into the fiber coupler.

Then, orient the connector key in a way that it is pressed gently onto the right-hand side of the receptacle notch.

The tightened grub screw and the "right-hand orientation rule" for the connector, ensure a high reproducibility in mode field position and angle, which is especially important for attaching and reattaching polarization-maintaining fibers reproducibly.

### Can I attach a narrow key fiber cable to a fiber coupler with a wide key receptacle?

Yes, you can- without any problem. Simply adhere to the "right-hand orientation rule".

Generally, with any FC PC or FC APC type connector there is a freeplay when inserting the fiber into the fiber coupler. The free play in between the connector ferrule and receptacle is only a few microns, but necessary for inserting the ferrule without force. There is a difference between the receptable and key width for wide key (2.14 mm) and narrow key (2.0 mm) fibers. If you follow the so-called "right-hand orientation rule" you can reproducibly attach and reattach even PM fibers with narrow key receptacle to fiber couplers with wide key receptacle without difficulty.

"Right-hand orientation rule":

When the ferrule tip is safely located in the inner cylinder of the receptacle, align the connector to the receptacle axis and carefully introduce the connector into the fiber coupler. Then, orient the connector key in a way that it is pressed gently onto the right-hand side of the receptacle notch. The tightened grub screw and the "right-hand orientation rule" for the connector, ensure a high reproducibility in mode field position and angle, which is especially important for attaching and reattaching polarization-maintaining fibers reproducibly.

### Can I use an end cap fiber with a mating sleeve?

Since the radiation has already started to diverge within the end cap, a simple mating is no longer possible. Please use a [fiber-to-fiber coupler](#) in this case.

### What is the minimum bend radius for my fiber cable?

### Do you have a Ø 900 µm cable?

If yes, then the min. bend radius is 15 mm. More information can be found [here](#).

### Do you have a Ø 3 mm cable?

If yes, then the min. bend radius is 40 mm. More information can be found in the drawing [here](#).

## PM fibers

### I look at my fiber end face and do not see a Panda structure? Why is that?

Chances are, that the fiber is equipped with end caps, that do not have a Panda structure themselves. The Panda structure within the actual fiber cable is visible with special microscopes only.

## PM fiber coupling

### Can I also couple into the fast axis of a PM fiber cable?

Conventionally the linearly polarized laser radiation is coupled into the slow axis because of its lower sensitivity to fiber bending.

You can also couple light into the fast axis of a PM fiber cable. However, the bandwidth of the fiber is severely reduced and it is only advisable to couple in a wavelength close to the cut-off.

Please also keep in mind that Schäfter+Kirchhoff only specifies and tests as well as supplies measurement data for radiation coupled into the slow fiber axis. Measurement and test result will vary for coupling into the fast axis.

## ACCESSORIES

### POLARIZATION ANALYZER SK010PA

Measurement tool for coupling into polarization-maintaining fiber cables

### BULKHEAD FIBER ADAPTERS

Fiber Adapters without Optics

### FCCT01

Fiber connector cleaning tool

## RELATED PRODUCTS

### FIBER CABLES SMC

Single-mode fiber cables

### RGB LASER BEAM COUPLERS SERIES 60SMS

for coupling into single-mode and polarization-maintaining fiber cables

**RGB FIBER  
COLLIMATOR SERIES  
60FC**

for collimating radiation exiting an optical fiber or as  
an incoupler

**FIBER COUPLERS  
SINGLE-MODE/PM**

Fiber Couplers for coupling into single-mode and  
polarization-maintaining fiber cables

**FIBER COLLIMATORS  
SINGLE-MODE/PM**

Fiber Collimators for collimating light exiting a single-  
mode or polarization-maintaining fiber cable

This is a printout of the page <https://sukhamburg.com/products/fiberoptics/fibercable/pm.html> from 5/5/2024

## CONTACT

For more information please contact:

Schäfter + Kirchhoff GmbH

Kieler Str. 212

22525 Hamburg

Germany

Tel: +49 40 85 39 97-0

Fax: +49 40 85 39 97-79

[info@sukhamburg.de](mailto:info@sukhamburg.de)

[www.sukhamburg.com](http://www.sukhamburg.com)

## LEGAL NOTICE

**Copyright 2020 Schäfter+Kirchhoff GmbH. All rights reserved.**

Text, image, graphic, sound, video and animation files and their arrangement on Schäfter+Kirchhoff GmbH webpages are protected by copyright and other protective laws. The content may not be copied for commercial use or reproduced, modified or used on other websites. [\[more\]](#)

