

## SK-LASM-C-90-22-R010

Flexible scanning of curved surfaces



### FEATURES

- Corrosion evaluations on car rims or wheel segments, as well as on corrosion test panels.
- Color sensor head for color with 22 µm / pixel (1151 dpi)
- Partial scanning of installed parts on cars, e.g. wheels, doors, bumpers, etc.
- Imaging and optical quality control of any kind of coatings.
- Collaborative robot meets safety requirements ISO 10218-1 and ISO/TS15066 for human-robot interaction



## DESCRIPTION

The robot-guided line scan camera consists of a sensor head with a high-resolution line scan camera (monochrome or color) and integrated line illumination, that is mounted on a robot arm. The robot arm executes a scanning movement on a programmed path over the surface. The path programming is easy possible by manually setting of few waypoints. At the beginning of the movement, the control unit of the robot arm sends a trigger signal to the camera.

The camera starts the image data transfer to the computer with an adjustable delay. During the movement, the line signals are assembled one by one into a 2D image in the computer's RAM.

At the end of the movement, the computer displays the image on the monitor. The image processing and evaluation can be applied to the entire image after the scan is finished, or frame-by-frame already during the scanning process.

**Unlimited freedom with high safety**

Thanks to a 6-axis robot arm, there are almost no limits to the scanning of surfaces. Whether strongly curved, slightly twisted or a flat surface - all this is no handicap for the robot arm. This great freedom is supported by intuitive operation for creating the path for the scanning process. Waypoints can be set either by hand or in an easy-to-use software interface. When using the software interface, the robot arm can be controlled with high precision in both the position and angle of the sensor head.

The operator also benefits from the high safety of the robot arm thanks to force-torque sensors that comply with the standards DIN EN ISO 10218-1 as well as the requirements of DIN ISO/TS 15066. If too much force is applied, the robot arm switches off automatically. The operator must manually confirm the safety status in order for the robot to resume its work. This ensures safe operation in cooperation with humans.

**Bright-field and dark-field illumination**

To detect the relevant microstructures, [bright-field or dark-field illumination](#) is used.

With bright-field illumination, the light strikes the sample surface perpendicularly. Flat surfaces facing the sensor appear bright, the light hitting the edges is reflected away from the sensor. They appear dark.

With dark-field illumination, the light is directed onto the test surface with an angle. Only light from e.g. edges that cause the light to reflect into the sensor appear bright, flat surfaces e.g. facing the sensor appear dark.

The sensor head on the robot arm can be precisely adjusted in angle and can also precisely maintain this angle over a distance section. If the surface changes, the angle can be easily readjusted in the path planning.

**Corrosion Inspector Software**

The software SKan-CI offers a simple control for the scanner system. After scanning the test sample, you have a wide range of image processing functions to get the best input for the analysis.

SKan-CI automatically recognizes a predefined set of scribe patterns and also automatically assigns, measures and ranks the corrosion and delamination areas, infiltration patches, filament lengths and their distribution frequency. When desired, the interactive and manual measurement of corrosive phenomena can be performed by the operator.

The program saves the accepted corrosion analysis results as images and tabular data, together with the treatment and analytical processing information, for retrieval, comparison and documentation.

The software supports also the offline evaluation, without a connection to the Corrosion Inspector hardware. After loading a stored image, grayscaled or color, the corrosion phenomena can be evaluated with all available methods. This allows an independent reanalysis or a new evaluation.

## TECHNICAL DATA

SK-LASM-C-90-22-R010

**Sensor Head**

Line Sensor	3 x 4080 (RGB) pixels
Field Of View	90 mm
Resolution	22 µm / pixel, 1151 dpi
Features	White Balance, LUT
Illumination	Integrated coaxial white LED line light
Robot arm	
Scan length	max. 500 mm
Scanning velocity	100 mm/s

## TECHNOTES

- [Line Scan Camera Basics \(10\)](#)  
[What are Line Scan Cameras? How do you create an image? etc.](#)
- [What are Line Scan Cameras?](#)  
[Introduction and advantages of Line Scan Cameras](#)
- [Creating an image using Line Scan Cameras](#)  
[How to create an image, definition of line frequency, and how to improve an image](#)
- [Optical resolution](#)  
[Definition and comparison to conventional area cameras](#)
- [Synchronization](#)  
[Reasons for synchronization and definition of different synchronization modes](#)
- [Shading correction and white balance](#)  
[Why do you need shading correction and how to use white balance](#)
- [Sensor alignment](#)  
[How to properly align the line scan camera sensor](#)
- [Blooming and Anti-Blooming Correction](#)  
[What is blooming and how to correct it](#)
- [Spectral sensitivity](#)  
[Spectral sensitivity of different line sensors](#)
- [True color imaging technologies](#)  
[Color Calibration of RGB cameras](#)
- [Bright and dark-field illumination](#)  
[Details about the different illumination techniques.](#)
- [Article - On the trail of rust](#)  
[Evaluate corrosion test panels quickly and objectively.](#)

## DOWNLOADS



[Article\\_CorrosionAnalyzer.pdf \(Technote\)](#)

## ACCESSORIES

**SKAN-R** Program to control the image acquisition with robot arm

## RELATED PRODUCTS

**SK-LASM-M-90-11-R010** Monochrome robot-guided scanner with 11 µm resolution

**SK-LASM-C-90-22-J010** Color scanner with 22 µm resolution

**SK-LASM-80-40-49-J01** Monochrome scanner with 40 µm resolution

This is a printout of the page <https://sukhamburg.com/products/details/SK-LASM-C-90-22-R010> from 4/25/2024

## CONTACT

For more information please contact:

**Schäfter + Kirchhoff GmbH**

**Kieler Str. 212**

**22525 Hamburg**

**Germany**

**Tel: +49 40 85 39 97-0**

**Fax: +49 40 85 39 97-79**

**[info@sukhamburg.de](mailto:info@sukhamburg.de)**

**[www.sukhamburg.com](http://www.sukhamburg.com)**

## LEGAL NOTICE

**Copyright 2020 Schäfter+Kirchhoff GmbH. All rights reserved.**

Text, image, graphic, sound, video and animation files and their arrangement on Schäfter+Kirchhoff GmbH webpages are protected by copyright and other protective laws. The content may not be copied for commercial use or reproduced, modified or used on other websites. [\[more\]](#)